

FRIAMAT®

FRIAMAT BASIC eco

31.07.18
12:11

29 °C
230 V
50 Hz

Enter barcode
Read



Operating instruction

FRIAMAT basic eco



Contents

Page

1. Preliminary remarks	4
1.1 Safety instructions and hints	4
1.2 Intended use	4
2. Safety	5
2.1 Functional reliability	5
2.2 The operator's obligations	5
2.3 Sources of danger	6
2.4 Mains operation	6
2.5 Generator operation	7
2.6 Extension cable	8
2.7 Opening the device	8
2.8 Safety measures at the installation site	8
2.9 Emergency	8
3. Basic information	9
3.1 Layout/parts	9
3.2 Function keys explained	10
3.3 Display	11
3.4 Function key symbols explained	12
3.5 Function status symbols explained	12
3.6 Type plate	12
3.7 Reader wand	13
3.8 Scanner	13
3.9 Protective cap for data interface	13
3.10 Temperature probe	14
3.11 Fan functionality	14
3.12 FRIAMAT preCHECK function	14
3.13 Signalling devices	15
3.14 Technical details	16
3.15 Automatic activation of maintenance interval	17
3.16 Transport/storage/dispatch	17

Contents





Page

4. First use	17
4.1 Activating and registering the device	17
5. “Fusion” sequence	19
5.1 Siting, connection, and startup	19
5.2 Reading in the barcode	20
5.3 Starting the fusion procedure	21
6. FRIAMAT basic eco	22
6.1 “Basic settings” menu	22
6.2 Install software update	22
6.3 Factory settings	23
6.4 Info	23
6.5 Emergency Input	24
7. Warranty / maintenance / disposal	25
7.1 Warranty	25
7.2 Yearly maintenance and care	25
7.3 Disposal	26
8. Error messages / warnings / info	27
9. Annex	30
9.1 Authorised service stations	30
9.2 Updates to these operating instructions	30

1. Preliminary remarks

1.1 Safety instructions and hints

In these operating instructions, the following symbols with warnings are used:

Symbol	Meaning
	Danger to persons. Failing to observe this can cause death or serious injury.
	Danger to persons. Failing to observe this can cause low to medium severity injuries.
	Danger to objects. Failure to comply can result in objects damage.
	Application tips and other useful information. Failing to observe this cannot cause injury.

1.2 Intended use

FRIAMAT fusion units are designed to apply a maximum fusion voltage of 48 V on the following:

- FRIALEN® safety fittings with HDPE pressure pipes (SDR 17-7),
- FRIALEN® XL large pipe installations with HDPE pressure pipes (SDR 17-7), and
- FRIAFIT® sewage fittings with HDPE sewage pipes (SDR 17-33).

FRIAMAT fusion units can also be used on fittings from other manufacturers when these components bear a 24 digit barcode complying with ISO 13950:2007-03. With the optional 1D/2D scanner, the FRIAMAT is also ready to read and process 2D barcodes according to ISO 12176-5. The power ratings and technical data of both the fittings and the FRIAMAT fusion unit must be observed (see also Section 3.14 “Technical data”).

Intended use also includes adherence to:

- all of the instructions in these operating instructions,
- the general and specific processing specifications for electrofusion fittings, and
- the applicable accident prevention regulations, the environmental regulations, the statutory rules, the pertinent safety provisions, and all standards, laws, and directives applying in the country of use.

2. Safety

2.1 Functional reliability

FRIAMAT fusion units are state of the art, built in accordance with the requirements under ISO 12176-2 and the acknowledged safety standards and fitted with the required safety devices. Prior to delivery, FRIAMAT fusion units are tested for correct and safe functioning. Failure to operate or otherwise use the equipment properly will pose a danger to:

- the health of the operator,
- the FRIAMAT fusion unit or other property of the user, or
- the efficiency of work with the FRIAMAT fusion unit.

Safety considerations forbid the following:

- modifications and changes to the FRIAMAT fusion unit and
- working with FRIAMAT fusion units with broken lead seals. Failing to observe the above makes all warranty claims void.

2.2 The operator's obligations

Only trained personnel may work with the FRIAMAT fusion unit. In the work area, the operator is responsible for all third parties. The owner is obliged:

- to make the operating instructions accessible to the operator and
- to ensure that these instructions have been read and understood.

The operating instructions must be kept at all times at the device's place of use (ideally in the mesh pocket on the transport box). They must be accessible to the operator at all times.

2.3 Sources of danger



Electric shock from live parts! Danger of death!

- Never leave the FRIAMAT fusion unit unattended.
- Immediately replace damaged housings, connecting lines, and extension cables. Stop using the FRIAMAT fusion unit.
- Before all care and maintenance work, pull out the plug connecting the equipment.
- Maintenance and repair work must be performed by authorised Aliaxis Deutschland service stations only.
- Supply FRIAMAT fusion units only with the operating voltage specified on the ratings plate.
- Fit a residual current protective device (RCD) when this is prescribed.
- Do not remove or otherwise put safety installations out of operation.
- Immediately eliminate identified defects.



Danger of fire and explosion from highly flammable materials and potentially explosive atmospheres!

- Keep away from flammable liquids and gases.
- Do not use in potentially explosive atmospheres (e.g. in areas where flammable gases, solvent vapours, or ignitable dusts can accumulate).
- Never leave the FRIAMAT fusion unit unattended.

2.4 Mains operation

Out of doors (building sites), power outlets must be fitted with residual current protective devices (RCDs). The regulations governing RCDs must be observed here.

NOTICE

Before commencing fusion, check the input voltage. The FRIAMAT fusion unit is designed for an input voltage range of 190-250 V!

2.5 Generator operation

NOTICE

Only those generators must be used that have been designed for industrial use on building sites. The operating instructions for the generator must be observed!

The use of generators must comply with DVGW work sheet GW308, VDE 0100 Part 728, and the specifications and guidelines applying in the country of use.

INFORMATION

The rated power output required from the generator depends on the level needed for the largest fusion fitting, the connection conditions, the ambient conditions, the generator type, and its control characteristics. Generators from different series exhibit highly diverse control characteristics. The suitability of a specific generator, therefore, cannot be safeguarded even when it provides the required rated power output according to its technical data sheet.

In cases of doubt, e.g. when acquiring new equipment, contact our service hotline +49 (0)621 486-1533!

Use only those generators that operate with frequencies within 44-66 'Hz.

First start the generator, and let it run for half a minute. If necessary, adjust the no-load voltage, limiting it to the voltage specified in the technical data. The generator (mains) fuse must be at least 16 A (slow blow).

NOTICE

During fusion, do not operate any other consumer from the same generator!

On finishing fusion work, first pull out the plug connecting the device to the generator, and then switch off the generator.

2.6 Extension cable

When using an extension cable, make sure it has an adequate conductor cross section:

- 2.5 mm² up to 50 m in length or
- 4 mm² up to 100 m in length.

NOTICE

Danger of overheating in the extension cable!

The extension cable may be used only when it has been completely unwound and stretched out.

2.7 Opening the device



Electric shock from live parts! Danger of death!

- Never open the FRIAMAT fusion unit when it is supplied with operating voltage!
- FRIAMAT fusion units may be opened only by specialised personnel from an authorised Aliaxis Deutschland service station!

2.8 Safety measures at the installation site

The connecting and fusion cables must be protected against sharp edges. Do not expose the FRIAMAT fusion unit to heavy mechanical loads.

FRIAMAT fusion units are splash proof. They may not, however, be immersed in water.

2.9 Emergency

In emergencies, immediately set the main switch to OFF, and disconnect the FRIAMAT fusion unit from the voltage supply.

3. Basic information

3.1 Layout/parts



1 Main switch

2 Fusion cable with reader wand

or barcode scanner

3 Front foil with display

and function keys

4 Service interface (USB)

with protective cap


5 Ventilation slots (air outlet)

6 Adapter bag

7 Power cable

8 Ventilation slots (air intake)

3.2 Function keys explained



1 Function keys

The three blue function keys let you access the function key symbols shown on the display.

2 Direction keys

The direction keys (left/right/up/down) let you move the cursor through the menu structure. The selection is confirmed with OK or one of the function keys.


3 START key

The START key is used to start a fusion procedure. This key is also used to confirm messages on the display.

4 STOP key

The STOP key is used to abort a fusion procedure, to close sub- or individual menus, and to cancel an input (without saving).

3.3 Display



1 Function status symbols

Symbols appear representing the functions that can be activated at this time. See also Section 3.5. Also shown is the next due maintenance (see also Section 7.2).

2 View ambient details

Key ambient details are shown (date, time, ambient temperature, voltage, and frequency).








3 Main window

The main window presents all inputs and details in each of the menus.


4 Guide key symbols

This presents the functions that are activated at each of the blue guide keys. The symbols shown vary depending on the menu selected (see also Section 3.4).

3.4 Function key symbols explained

Symbol	Designation	Description
	Menu key	This opens the main menu
	Input / emergency input key	This lets you input a barcode manually, e.g. when it cannot be read. This opens a virtual keypad.
	Confirm key	Depending on the context: OK, Confirm, Apply, Save, Select (a menu item)
	Cancel key	This ends an input and closes the dialog without saving
	Back key	This takes you one step back in a menu, sequence, or input (without changes)
	Next key	This takes you to the next step in a sequence or input
	Backspace key	This virtual key (emergency inputs) deletes the character to the left of the cursor.

3.5 Function status symbols explained

Symbol	Description
	Maintenance date: This is the next due maintenance shown in days.

3.6 Type plate

The type plate lists the details specific to the FRIAMAT fusion unit and its unique device number.

3.7 Reader wand

To read in fusion barcodes and traceability barcodes, place the reader wand under a slight angle (like a pencil) in front of the barcode on the fitting. Now move the reader wand quickly over the whole label and a little beyond. Barcodes can be read in from right to left or vice versa. When the barcode has been read in correctly, the device emits an acoustic signal to confirm this. If the barcode cannot be read in the first time, repeat the procedure, this time under a different angle or at a different speed.

NOTICE

Protect the tip of the reader wand from dirt and damage!

The condition of the reader wand tip has a direct effect on the legibility of barcodes.

3.8 Scanner

The mini scanner reads in 1D fusion and traceability barcodes without physical contact. If fitted with the (optional) 1D/2D scanner, it can also read in 2D barcodes complying with ISO 12176-5. All you need to do is aim at the barcode and press the read button. The barcode is scanned by means of a red light strip that must cross over the whole barcode, whenever possible at the centre. The barcode is not detected properly when the red light strip does not cross the whole barcode.

The optimal read results are obtained when the scanner is positioned at a small distance over the barcode. When the barcode is read in successfully, the device emits an acoustic signal.

NOTICE

Protect the reading window from dirt and scratches!

The condition of the reading window has a direct effect on the capabilities of the FRIAMAT barcode scanner.

3.9 Protective cap for data interface

The USB port is found directly behind the protective cap. This data interface functions as a service port. The protective cap for the data interface must be screwed on at all times to prevent contaminants and moisture from reaching it.

3.10 Temperature probe

FRIAMAT fusion units can be used only on electrofusion fittings bearing a barcode. When this is read in, the microprocessor controlled FRIAMAT fusion unit regulates and monitors the supplied energy fully automatically and defines the fusion time as a function of the ambient temperature. This ambient temperature is continuously measured by the temperature probe on the fusion cable.

Make sure that both the temperature probe and the fusion fitting are exposed to the same ambient temperatures. Avoid adverse processing situations, e.g. where the probe is exposed to intense sunlight and the fitting is in the shade. The temperature probe must be protected against damage.

3.11 Fan functionality

How the fans function depends on the temperatures measured at the heat sink inside the FRIAMAT fusion unit. The fans switch ON automatically when the heat sink reaches a certain temperature. And this not only during, but also between fusion sessions, or after reactivation, depending on the load levels. This safeguards reliable operations in continuous duty and during fusion on large dimensions.

INFORMATION

Reduce cooling times!

In particular during series fusion work or work on fittings requiring high power levels, leave the FRIAMAT fusion unit switched ON after each fusion. The fans can then reduce the heat sink temperature.

3.12 FRIAMAT preCHECK function

Standard procedure:

Before every fusion process, the FRIAMAT conducts a preCHECK. This involves the device calculating from the fitting parameters, the current device status, and the ambient temperature whether this fusion can be executed to the end. Not until then can the fusion be started, and performance related fusion stops are reliably prevented as a result.

Multiphase fusions based on 2D barcodes complying with ISO 12176-5:

Thanks to the new 2D barcode standard ISO 12176-5, it is now possible for the first time to perform multiple fusions / fusion phases without repeated barcode reads. Performing two to nine fusion phases is termed multiphase fusions. This means that up to nine fusions can be performed immediately in succession on the one fitting / component. When this 2D barcode standard with multiphase fusions is applied, the FRIAMAT preCHECK function is **deactivated**. When the

2D barcode standard ISO 12176-5 is applied with only one fusion, the FRIAMAT preCHECK function is activated.

NOTICE

When multiple fusions are performed without the FRIAMAT preCHECK function, very long duty cycles may cause excessive heating on the fusion unit. To prevent heat damage to the unit, the device is designed to stop the fusion process. A fusion process stopped in this manner is then unfinished. Once the fusion joint has cooled down fully, fusion must be repeated. Observe here the processing instructions from the fitting manufacturer.

INFORMATION

When performing multiphase fusions complying with ISO 12176-5 over long duty cycles, use the device only in a cooled state. This generally helps to avoid any undesirable stops to fusion

3.13 Signalling devices

FRIAMAT fusion units confirm certain sequences of operations by emitting an acoustic signal (1, 2, 3, or 5 beeps). These signals mean the following:

- 1 beep means: Read barcode confirmed.
- 2 beeps mean: Fusion procedure ended.
- 3 beeps mean: Supply voltage too low / too high.
- 5 beeps mean: Error! See display!

INFORMATION

Adjust the volume!
The volume of these signals can be set to “high” or “low” in the “Basic Settings” menu. See also Sections 6.1.

3.14 Technical details

Technical details*	FRIAMAT basic cco
Input voltage range	AC 190 V – 250 V
Frequency range	44 Hz...66 Hz
Input current	AC 16 A max.
Output	3,5 kW
Generator rated output for fittings d 20 – d 160 d 180 – d 900	~ AC 2,4 kW ~ AC 5,0 kW
Unit fuse	16 A slow blow
Housing	international protection IP 54 DIN EN 60529 protection class I DIN EN 60335-1
Connecting cable	5 m with contoured plug
Fusion cable	4 m with fittings plug, ø 4 mm
Barcode type	code 2/5 interleaved according to ANSI HM 10.8 M-1983 and ISO CD 13950/08.94 2D-code (QR; Aztec; Data Matrix) according to ISO 12176-5
Operating temperature range**	-20°C...+50°C**
Fusion current monitoring	short circuit 110 A short circuit 1.70 x IN interrupt 0.25 x IN
Fusion voltage	max. DC 48V
Service port	USB
Languages	Bulgarian, Chinese, Croatian, Czech, Danish, Dutch, English, Estonian, Finnish, French, German, Hebrew, Hungarian, Italian, Latvian, Lithuanian, Polish, Portuguese, Romanian, Russian, Slovakian, Slovenian, Spanish, Swedish, Turkish
Dimensions W x D x H	260 x 500 x 340 mm
Weight	approx. 18 kg
Accessories	operating instructions, transport box
Overvoltage classification	Category II
Certificate/quality	CE, ISO 9001, WEEE Reg. No. DE 49130851, RoHS, REACH

*: Specifications subject to change.

** : Fusion work on fittings from other manufacturers must comply with their respective working temperature ranges!

3.15 Automatic activation of maintenance interval

The maintenance interval stored in the FRIAMAT fusion unit (default: 12 months, see also Section 7.2) is not activated automatically until after the first fusion.

INFORMATION

The leading maintenance date is always shown on the display and may differ from the details on the service label attached to the FRIAMAT fusion unit!

3.16 Transport/storage/dispatch

The FRIAMAT fusion unit is delivered in a transport box. This transport box keeps it dry and protected against moisture. The box should always be used to transport the device. The temperature range for storage is -20 °C to +70 °C.

4. First use

When the FRIAMAT fusion unit is used for the first time, the user will be prompted once only to set the display language, the log language, and the country of use. These settings can be edited at any time at their respective function keys in the menu “Basic Settings” (see Section 6.1).

4.1 Activating and registering the device

Before the user can activate and operate the FRIAMAT fusion unit, he must first complete the activation dialogue now opening. Here the user must use a smartphone’s camera to capture the QR code appearing on the FRIAMAT fusion unit’s display. Then he must tap the URL now appearing, and start entering the activation data on the smartphone. An external app for capturing the QR code is now no longer necessary on Android 9.0 and Apple iOS 11 systems or later.



INFORMATION

Instead of scanning the QR code, the user may as an alternative enter the URL <https://alixis.de/sw-update> in the smartphone.

This URL opens on the user’s smartphone the registration dialogue where he must enter the ID no. of the device he wants to activate, his company, and an email address of the device’s owner. We recommend entering an email address that is not subject to regular revision nor contains any personnel related data. Once the user has confirmed the entered data, a four digit activation PIN is sent to the entered email address. This four digit activation PIN must then be entered in the activation dialogue on the FRIAMAT fusion unit’s display.

INFORMATION

If using entered personal data:

Any personal email address entered in the FRIAMAT fusion unit's activation dialogue will be stored and used by Aliaxis Deutschland as a fast, simple means to inform this email address's owner of the availability of new software updates and new device features

To skip the activation dialogue, press the Cancel key to activate the device at a later time. In this case, the prompt to activate the device will appear every time the FRIAMAT fusion unit is switched on.

INFORMATION

Device registration in the customer portal at www.aliaxis.de/portal/en

Independently of the activation dialogue on its display, the FRIAMAT fusion unit can also be registered www.aliaxis.de/portal/en via the FRIAMAT Software Update module in the Aliaxis Deutschland GmbH customer portal at www.aliaxis.de/portal/en. This, though, does not activate the FRIAMAT fusion unit, and no activation PIN is generated.

Software update

The "FRIAMAT Software Update" module provides the possibility to receive new device-specific information and innovations by email for registered fusion devices, as well as to download available software updates.

After registration of the device in the "FRIAMAT Software Update" module, update notifications and additional, ongoing device-specific information and innovations for the registered FRIAMAT fusion devices will be sent by email from Aliaxis Deutschland and its affiliated companies to the email address which are stored in the user account of the customer portal.

The user can download software updates and install them on the device themselves (refer to Chapter 6.2. Install software update, P.22).

INFORMATION

In case of sale of the registered FRIAMAT fusion unit, the user has to inform the new owner about the update possibilities and the use of the module "FRIAMAT Software Update" in the customer portal on www.aliaxis.de/en and to inform Aliaxis Deutschland about the change of ownership, naming the new owner.

5. “Fusion” sequence

5.1 Siting, connection, and startup

Before every use, you should check that the FRIAMAT fusion unit is not damaged and operates properly within the specifications. All parts must be correctly installed and all conditions fulfilled. Only then can the device operate properly.

The FRIAMAT fusion unit can be sited and operated out of doors when it is protected against rain and moisture.

1. The FRIAMAT fusion unit must be sited on level ground.
2. Prepare the fitting and pipes for fusion in compliance with the assembly instructions.
3. Make sure that the fitting’s contact pins are accessible for connection to the fusion plugs.



Danger of overheating in the cables!

Before use, all cables must always be unwound completely. This applies to the device, fusion, and extension cables.

4. Connect the device to the power supply (mains or generator).
To do so, insert the device’s plug into the socket.
5. If necessary, use an extension cable. Make sure that the conductor cross section is adequate (see also Section 2.6).
6. When operating with a generator, make sure that it is fused with at least 16 A (slow blow, see also Section 2.5).
7. When operating with a generator, first start the generator and let it warm up for 30 s.
8. Switch ON the FRIAMAT fusion unit at its main switch.

CAUTION!

Danger of scorching!

The contact areas on the fusion plugs and fitting must be clean. Soiled contacts can cause the plug to overheat, damaging it.

- If necessary, wipe clean of any contaminants.
- You must always protect the plugs against soiling.
- When a deposit has formed that cannot be removed completely, the fusion plugs must be replaced.
- First examine the fusion plugs and the fitting's insert contacts for soiling, then connect them.

NOTICE

Only original FRIATEC fusion plugs (art. no. 624529) may be used!

9. Connect the fusion plugs to the contact pins on the fitting.
10. The fusion plugs must be attached completely to the fitting's pins, i.e. over their whole internal contact length.

5.2 Reading in the barcode

1. Read in the barcode: use exclusively the barcode affixed to or provided with the contacted fitting.
2. If the barcode label is missing or damaged, you can use the barcode on an identical fitting from the same manufacturer and the same charge. In cases of doubt, contact the fitting manufacturer's hotline.

NOTICE

It is forbidden to read in a replacement barcode on a different fitting!

3. Read in the barcode with a reader wand or mini scanner, or the 2D barcode with a 1D/2D scanner (see also Sections 3.7 and 3.8).
4. A correctly read barcode is confirmed with an acoustic signal.

INFORMATION

When an acoustic signal is not emitted, examine the reader wand or barcode scanner for soiling or damage. If necessary, you can also perform the fusion in emergency input mode (see Section 6.5)!

5.3 Starting the fusion procedure



Danger of burning injury!

In rare cases, hot PE melt can exit when the fusion sequence malfunctions. A safety distance of at least 1 m must be kept from the fusion site.

NOTICE

Do not connect any other consumers during fusion!

You can stop the fusion procedure at any time by pressing the STOP key. Fusion can be resumed after the fusion joint has cooled completely (and all causes of the fault have been eliminated). Observe here the processing instructions from the fitting manufacturer.

INFORMATION

When an acoustic signal is not emitted confirming the read-in process, examine the wand or barcode scanner for soiling or damage. If necessary, you can also perform the fusion in emergency input mode (see Section 6.5)!

Operating step

1. **“Pipe Processed?”** appears on the display. When applicable, confirm this with the (START) or the (Next) function key.
2. The fitting data then appear again. These must be checked and confirmed by the user.
3. Press the (START) key to initiate the fusion procedure. The ambient temperature is measured, and the resistance of the connected fitting determined (“Check” appears on the display). The connected fitting and the FRIAMAT preCHECK function are now checked. On positive results, fusion starts automatically. The display shows the fusion progress. This shows in seconds the duration of fusion and the fusion time left.
4. “Fusion successful” on the display means: Fusion procedure has ended. “Fusion time nom” and “Fusion time act” mean nominal and actual fusion time and must agree.
5. Note the fusion parameters on the pipe/fitting. This also serves to prevent double fusions.
6. “Fusion successful” with “Fusion time nom” and “Fusion time act” must always be acknowledged with OK or, alternatively, with the START or STOP key. The fusion procedure has ended, and the FRIAMAT fusion unit is ready for the next fusion.

6. FRIAMAT basic eco

6.1 “Basic settings” menu

The function key in the main menu opens the submenu “Basic settings”. Here you can edit the device settings.

DATE AND TIME

* SYSTEM LANGUAGE *

VOLUME

UPDATE

FACTORY SETTINGS

1. Press the (Menu) function key. This opens the main menu.
2. Press the direction keys to open the “Basic Settings” submenu.
3. Press the (Confirm) function key or OK.
4. Use the direction keys to open the menu for Time, Date, Language, and Volume.
5. Press the (Confirm) function key or OK.
6. Use the function and direction keys to make your changes and edit the settings.
7. Press the (Confirm) function key or OK to save your changes.

INFORMATION

The “Basic settings” menu contains the item “System language” preceded and followed by two asterisks. This lets you find the system language settings menu when, for instance, the language was changed by accident.

6.2 Install software update

INFORMATION

When the update cannot be installed on the device, then immediately contact the authorised service station or the local service partner or Aliaxis Germany (refer to Chapter 9.1. Authorised service stations, P.30).

Prerequisites

- A commercially available computer with USB port and Internet access
- USB stick which is formatted in FAT 32 with up to 256 GB

1. Call up the customer portal via a browser: www.aliaxis.de/portal
2. Navigate to the "FRIAMAT Software Update" module in the customer portal.
3. Download the update.

Every update comprises a data package with several files in which the following information is provided:

Instructions for executing the update, information about system prerequisites hardware prerequisites for downloading and transferring.

4. Always follow the instructions for executing the update.
5. Always ensure the system and hardware prerequisites.
6. Copy the data files from the computer to a USB stick.
7. Calling up the menu item in the display:
Main menu basic setting, update.
8. Connect a USB stick.
9. Follow the instructions for the update.
10. Follow the instructions on the display.
11. After a successful update, please switch the device OFF and ON again.

6.3 Factory settings

In the submenu "Factory settings" the FRIAMAT fusion unit can be reset to factory settings. Afterwards, the display language, protocol language and country of operation must be set again (see also Chapter 4).

INFORMATION

No fusion data is deleted from the memory by resetting to the factory settings.

6.4 Info

The corresponding function key (menu) opens the submenu "Info". Here you can request device information, device features and licenses.

DEVICE INFORMATION

DEVICE FEATURES

LICENSES

1. Press the (Menu) function key. This opens the main menu.
2. Press the direction keys to open the "Info" submenu.
3. Press the (Confirm) function key or OK.
4. Select single menu (device information, device features, licenses) with the direction keys.
5. Press the (Confirm) function key or OK.

Under "device information" the following requests can be displayed:

TYP
UNIT NUMBER
SW-HMI
SW-PU
MAINTENANCE DATE

Under the submenu "device features" function information can be displayed. Here are several functions listed which your FRIAMAT possess and execute. In addition, further functions can be displayed for which your FRIAMAT is prepared.

Under the submenu "Licences" you can check license information.

6.5 Emergency Input

The "**Emergency Input**" menu lets you enter the fusion barcode manually.

1. Press the (Input/Emergency Input) function key.
2. Enter each of the numbers in the barcode using the direction keys on the number pad now appearing. When finished, press OK.
3. Press the (Confirm) function key to save the entered numbers, the (Cancel) function key to abort the input, or the (Backspace) function key to delete preceding numbers.
4. The (Back) function key deletes the last input.
5. If entered correctly, the number on the display is the same as the barcode read in with the reader wand or scanner.

INFORMATION

No numbers are shown when this function is used for the first time. Afterwards, the last barcode entered manually is always shown!

7. Warranty / maintenance / disposal

7.1 Warranty

FRIAMAT fusion units come with a 24 month warranty.

7.2 Yearly maintenance and care

Under 7.1 of the international standard ISO 12176-2 “Plastics pipes and fittings – Equipment for fusion jointing polyethylene systems – Part 2: Electrofusion”, an electrofusion unit must maintain the required operating precision at the maximum and minimum ambient temperature for at least twelve months only, without the need to reconfigure the control unit.

As a measure to safeguard the consistency of this operating precision during the whole warranty period beyond these twelve months (see also Section 7.1), it is imperative that the FRIAMAT fusion unit is serviced **at least once a year**.

This maintenance includes examining whether the FRIAMAT fusion unit still exhibits the required operating precision or whether it has to be recalibrated.

Also in accordance with DVS 2208 Part 1 and DGUV V3 (formerly BGV A3) (“Electrical systems and equipment”), nonstationary electrical equipment must be subjected to repeat tests **at least once a year**.

If pertinent generally accepted engineering standards applying to the FRIAMAT fusion unit’s site prefer a maintenance period of less than one year, this shorter period must be observed without fail.

This maintenance can be performed at Aliaxis Deutschland GmbH or one of its authorised service stations (see Section 9.1).

Also all connection adapters must be submitted for tests on the maintenance dates.

What?	When?	Who?
Clean the reader wand or barcode scanner, and check for damage.	Daily	Operator
Check function.	Before every use	Operator
Check, and, if necessary, clean or exchange contacts.	Before every use	Operator
Factory maintenance	Yearly	Aliaxis Deutschland GmbH or authorised service stations

7.3 Disposal

The European Directive 2002/96/EC on waste electrical and electronic equipment (WEEE) regulates the disposal of used electrical and electronic products. The WEEE Directive 2005 was implemented as the ElektroG on the German disposal sector. Under these laws, waste electrical and electronic equipment must be introduced to a proper disposal or recycling process. FRIAMAT fusion units fall under this European Directive and can be submitted for disposal to Aliaxis Deutschland GmbH or one of its authorised service stations.

Further regulations, standards, and directives applying in the country of use must be observed.

8. Error messages / warnings / info

Irregularities during fusion cause error messages or warnings to appear on the display of the FRIAMAT fusion unit.

INFORMATION

On the FRIAMAT basic eco, press the function key to view the displayed error message in plain text!

INFORMATION

Should the FRIAMAT fusion unit output an error message or warning that is not listed in the following and that cannot be explained or remedied despite the plaintext description, contact our service hotline +49 (0)621 486-1533!

No.	Displayed text	Meaning/causes	Remedy
02	Temperature out of range	Ambient temperature outside of permitted range.	You may have to tent over or shield the fusion area
03	Resistance outside of tolerance	Fitting's electrical resistance outside of tolerance.	Check that contacts sit firmly and are clean. If necessary, clean contacts and replace the fitting.
04	Fitting's wire turn short circuited	Short circuit in the fitting's wire turn.	Replace fitting, and send it in for analysis.
05	Fitting's wire turn interrupted	Current flow interrupted	Check the connection between the fusion plug and the fitting. If OK, replace fitting, and send it in for analysis.
06	Voltage outside of tolerance	Deviation in fusion voltage too high.	Notify authorised service station.
08	Operating voltage out of range	Operating voltage outside of permitted range during fusion.	Extension too long, or cross section too small. Check voltage and connection conditions on the generator.
09	Frequency out of range	Frequency outside of permitted range during fusion.	Check frequency of generator voltage

No.	Displayed text	Meaning/causes	Remedy
10	Fusion stop	Fusion stopped at STOP key.	–
12	Device overheated	Protective function that prevents the device from overheating.	Let the device cool down. The fans reduce the temperature of the device when it is switched ON.
13	Operating voltage failure	Supply voltage interrupted (e.g. power failure during fusion) or too low.	Check connection conditions.
14	Power too low	Fitting's power input is too low. The FRIAMAT cannot provide such a low power.	Contact the Aliaxis Deutschland service hotline: +49 (0) 621 - 486 1533
15	Power exceeded	The fitting's power input exceeds the capacity of the FRIAMAT.	Contact the Aliaxis Deutschland service hotline: +49 (0) 621 - 486 1533
17 - 19	System error		Contact the Aliaxis Deutschland service hotline: +49 (0) 621 - 486 1533
23	Generator error	Generator possibly not suitable for fusion.	Contact the Aliaxis Deutschland service hotline: +49 (0) 621 - 486 1533
30	Fan blocked or defective		Contact the Aliaxis Deutschland service hotline: +49 (0) 621 - 486 1533

Displayed text	Tip/remedy
Attention! Double fusion!	Message is displayed when a fitting has been tried to fuse once again. Nevertheless, if you intend double fusion on a fitting, you must disconnect the fusion unit's pins from the fitting after the first fusion, and let it cool down (see the processing instructions issued by the fitting manufacturer).
Defect/incorrect barcode	Use a new barcode on an identical fitting, or correct the entered code manually.
Let the device cool down.	Protective function that prevents the device from overheating. Let the device cool down. The fans reduce the temperature of the device when it is switched ON.
Fusion stop	Fusion stopped at STOP key.
End of fusion	Fusion finished.
Checks	Checks on the fitting data and FRIAMAT preCHECK function.
Voltage ... V; frequency ... Hz	Adjust generator, and acknowledge at STOP key.
Maintenance date exceeded	Have the device serviced by Aliaxis Deutschland GmbH or an authorised service station.
FRIAMAT preCHECK deactivated	When the 2D barcode complying with ISO 12176-5 is applied with multiphase fusions, the FRIAMAT preCHECK function is activated

9. Annex

9.1 Authorised service stations

Please contact the Aliaxis Deutschland GmbH service hotline +49 (0)621 486-1533 for service stations worldwide.

9.2 Updates to these operating instructions

The technical information contained in these operating instructions are reviewed regularly and updated. The date of the last revision is specified on every page.

The latest operating instructions can be viewed on the internet at www.aliaxis.de. The download section can be accessed via the navigation bar and this provides our updated operating instructions in the form of PDF documents.

Aliaxis Deutschland GmbH

Infrastruktur
Steinzeugstraße 50
68229 Mannheim
Tel +49 621 486-2828
Fax +49 621 486-1598
info.de@alixis.com
www.alixis.de

Aliaxis Deutschland GmbH

Infrastructure
Steinzeugstraße 50
68229 Mannheim, Germany
T +49 621 486-2238
info.de@alixis.com
www.alixis.de

